

Es kann verschiedene Gründe geben, warum Wasser am Verbindungsschlauch erscheint :

- Easy Clix® ist nicht richtig fixiert, also nicht weit genug geschoben und es macht nicht „Clix“, d.h. es schließt nicht richtig und dichtet damit nicht sauber ab (falsche Handhabung).
- Die orangene Schiebesicherung am Winkelanschluss ist verdreht (Foto „wrong“).
- Es tropft ggf. am Winkelanschluss zum Sockel (und nicht am Easy Clix® Anschluss), das kann dann sein, wenn der Winkelanschluss zu weit rein- oder rausgeschraubt wird und der Dichtring des Winkelanschlusses dadurch keine Wandung mehr am Sockel findet, um abzudichten. Es tropft auch dann, wenn der Dichtring aus unbekanntem Grund nicht mehr vorhanden ist (nur Classic Line).



There could be different reasons why there is a leak of water at the connection hose:

- The Easy Clix® connection is not properly fixed, perhaps it is not pushed far enough and made no „clix noise“ by that, so it does not close and seal properly (wrong handling).
- The orange cap closure of the Easy Clix® is twisted (image „wrong“).
- Possibly it drips at the angle connection to the base. That can be, if the angle connection is screwed in or out too far and the sealing ring of the angle connection does not seal properly against the wall setting of the base. It even drips when the sealing ring is not there anymore (only classic line).

